

# TEXRECO CONTRACT

## **WALL COVERING**

Technical Data Sheet Revised: 04/2021

#### **DESCRIPTION**

Ready-mix adhesive especially developed for all kinds of contract wall coating.

- + Very strength
- + Doés not stain
- + High yield
- + Low V.O.C. content
- + Contains antibacterial and anti-mold additives

#### Suitable for:

- Vinyl contract wall coverings with fabric or non woven backing with a weight up to 1 kg/m²
- Fiberglass wall coverings
- Paintábles wall coverings

#### **SURFACE PREPARATION**

All surfaces must be dry, absorbent, strong, free of dust or paints or oils

Any cracks or holes in the wall must be covered with our extra-light GLASTER and in case of imperfections shaved with a normal stucco plaster.

We always recommend the use of our PRIMER AC fixative for consolidation and cleaning.

We recommend using our PRIMER SP (specific for wet walls with fungi and mold) in case of rising damp or too humid.

### PREPARATION OF ADHESIVE

TEXRECO CONTRACT SUPER STRONG is ready to use. If necessary, dilute with 5% clean water.

#### **APPLICATION**

TEXRECO CONTRACT SUPER STRONG is applied in a single coat with a brush, roller, spatula or pasting machine.

BRUSH - Apply TEXRECO CONTRACT SUPER STRONG on the back of the wall covering. Fold the sheet back on itself and wait 10 - 20 minutes depending from the ambient temperature. Then proceed to apply of the sheet.

Video tutorial: https://www.youtube.com/watch?v=j7zO9ekpbRg

ROLLER - APPLY TEXRECO CONTRACT SUPER STRONG directly on the wall with short wool roll for about 10/15 m<sup>2</sup>. Proceed accordingly to apply the wall covering.

Video tutorial: https://www.youtube.com/watch?v=2p-pteh2B1

SPATULA - Apply undiluted TEXRECO CONTRACT SUPER STRONG with a toothed spatula no. 1 directly on the wall. For 15  $\rm m^2$  proceed to apply the wall coverings.

Video tutorial: https://www.youtube.com/watch?v=316ytuK36rA

MACHINE - Dilute TEXRECO CONTRACT SUPER STRONG with 5/10% of water before to use the product.

#### **CONSUMPTION**

150 - 250 g/m<sup>2</sup>

#### **CLEANING**

We recommend cleaning the wall coverings from excess adhesive and the joints with a wet sponge.

Possible spillages of the adhesive should be removed immediately. We also recommend consulting the cleaning instructions of the wall covering's manufacturer before installation.

THE PRÓDUCT DOES NOT STAIN.

#### **CONTRAINDICATIONS**

TEXRECO CONTRACT SUPER STRONG is suitable on non-absorbent surfaces, imperfect prepared substrates, or humid walls. We suggest, in case of humid wall, to prepare the surface with ACM PRIMER SP.

#### **PACKAGES**

Bucket 5 Kg	code 10004-C-SS
Bucket 10 Kg	code 10005-C-SS
Bucket 15 Kg	code 10006-C-SS

#### **STORAGE**

TEXRECO CONTRACT SUPER STRONG is guaranteed for 24 months from the date of production. Preserve from frost ( $\pm$  5 °C  $\pm$  40 °C).

#### **TECHNICAL DATA**

base:	starch
physical appearance:	white cream
pH:	6.5
viscosity:	55000 - 65000 cps
V.O.C. content:	< 0,005 mg/m <sup>3</sup>
solid content %:	about 38%
customs code:	3505 2010
application temperature:	+ 5 °C + 40 °C
waiting time:	0 - 10 minutes
open time:	20 - 30 minutes
definitive adhesion:	48 hours
non flammable	

#### **FINAL PROVISIONS**

Keep out of the reach of children and pets. Discharge the waste in special containers for building materials.



